Universal Vent Installation Instructions

- 1. Cut a rectangular slot 2.5" x 8". DO NOT cut roof rafters.
 - a. For Exhaust: Place 8" to 24" from the ridge
 - b. For Intake: Place 12" to 36" from the eave
- 2. Apply sealant to underside of the flanges.
- 3. Slide upper flange under shingles. Make sure to align the ribs of the vent with the opening. If installing multiple vents, each vent should be at least 12" apart.
- 4. Recommended installation screw: #10 x 1 1/2" Sheet Metal Screw
- 5. Total number of screws needed = 6
- 6. Screws not included.



