

# Installation Instructions for the UV-60




## Step 1:

Cut a rectangular slot 2" x 32"

a. Exhaust: from the ridge 8" to 24"

b. Intake: from the eave 12" to 36"

**DO NOT** cut roof rafters, only cut an opening in the roof deck.




## Step 2:

Apply roofing grade sealant to the underside of the top and side flanges. Never put sealant on the bottom flange.



## Step 3:

Slide the upper flange under the shingles. The ribs are to align over the opening.



## Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963

Website: [roofvents.com](http://roofvents.com) Email: [sales@roofvents.com](mailto:sales@roofvents.com)


5777-10

# Installation Instructions for the UV-60



## Step 4:

When the UV is in its final position the top flange should be under the shingles, and the bottom flange should be on top of the shingles to ensure drainage.



## Step 5:


Required screw #10 x 1.5" steel sheet metal screw. With the vent in place secure the flange to the shingle roof using a screw gun or drill. All installation screws are placed at 1" from edge. Number of screws required: 17



## Step 6:

This is how the vent should look when installed.

**Note:** If installing multiple vents on roof each vent should be placed at least 12 inches apart.



## Active Ventilation Products, Inc.

311 First Street, Newburgh, NY 12550-4857

800-ROOF VENT (766-3836) Ph: 845-565-7770 Fax: 845-562-8963

Website: [roofvents.com](http://roofvents.com) Email: [sales@roofvents.com](mailto:sales@roofvents.com)

5777-10