

# ROUND BACK VENT

## PLACEMENT INSTRUCTIONS FOR PITCHED SHINGLE ROOFS

---

- Install vents on backside of the roof (for aesthetics).
  - Install vents at least 12-18 inches down from the peak of the roof.
  - Evenly space vents across the length of roof.
  - Never cut into a roof rafter (truss) when cutting a hole in the roof.
  - Placement of roof vents are always on either side of roof rafters when properly situated.
  - Confirm whether the 1/300 OR 1/150 rule for Application Square Foot is required.
  - Please call Active Ventilation Products at 800-roofvent (800-766-3836), for technical support.
- 

### HOW TO CALCULATE THE PLACEMENT OF THE EXHAUST VENTS ON PITCHED ROOFS:

**1. Calculate how many vents are needed:** (*refer to vent calculator on [roofvents.com](http://roofvents.com)*)


- Total Square Footage of roof ÷ Application per Square Foot of vent = Total Vents Needed

**2. Calculate placement of vents:**

- Total Length of Roof ÷ (Total Vents Needed + 1) = Distance between vents on roof



*Placement of vents should be evenly spaced across the length of the roof.*



**ACTIVE VENTILATION PRODUCTS, INC.**

**800-roofvent 800-766-3836**

roofvents.com • sales@roofvents.com • 845-565-7770